



Prosys 16 Panel

- 8 Zones expandable up to 16 Zones
- 4 Partitions to support multi-owner and separate account installations with one system
- 4 Groups per partition - enabling partial arm/disarming of a group of zones within a partition
- Up to 32 schedules for arm/disarm and output control, supporting 2 intervals per day
- Auto-Install TM technology
- High security features such as double password, key disable during scheduled arm, and two separate buses
- 6 Fully programmable Utility Outputs on board - one 3A relay, one 500mA open collector and four 70mA O.C.

- False alarm prevention features
- One-man walk test Up to 30 user codes
- Built-in siren driver (900mA)
- Fuseless technology
- Periodic self test system
- Up to 250 (Fixed) event log buffer
- Box tamper N/C
- Bell / siren tamper EOL
- Support bus zones