



Wisdom Wireless Panel

- 4-Button Keyfob (Arm/Stay Arm/Disarm/Panic)
- 33 Zones (32 Wireless + 1 Wired)
- 3 Partitions / Areas
- 32 User Codes
- 4 Utility Outputs Onboard
- Zone Supervision 250 Event Log